


What about my growing puppy?

The easyway™ collar adjusts to accommodate different breeds and growing dogs. A puppy may start in his adult-sized collar (or for large dogs, a size or two smaller), with shortened Chin Straps and Cheek Straps. These can be gradually lengthened as your puppy grows.

"We chose the NewTriX easyway collar after trying everything else. It is kinder to the dogs and easier for our volunteers to use in our foster program. The easyway collar is simply the best dog training tool on the market."
Chris Fowler, National Service Dogs



Cheek straps are a little loose and puckered out from the cheeks.



You cannot pull the nosepiece forward off his nose.



Your dog can yawn fully.



Cheek and chin straps are equal on both sides.

Tips for a Happy, Obedient Walker

Dogs love to run free, so it's only natural that your Dog will try to paw the unfamiliar strap from his nose.

Distract him from pawing at the easyway™ collar and reward him when he leaves it alone.

To ensure his safety, practice in an enclosed area with no distractions to capture your Dog's attention.

Lure your dog with a favourite toy or food treat and praise him with "happy talk" when he looks at you and follows your lead with a loose leash.

Make loose-leash walking a game. The stop signal for both of you is any tug on the leash. As soon as he stops, be sure to slacken the leash. Make him wait for you, and if he tries to lead, don't budge. Make your first move forward only if the leash is loose. To make it more fun, be harder to predict by randomly changing speed and direction.

Never jerk the leash. Think of it like power brakes, and keep a light touch.

For sales, support and more information, visit us at

www.newtrix.ca



NewTriX Inc.
2255B Queen St. E., #348
Toronto, Ontario
Canada M4E 1G3
1 866-384-2135
F 416 698-5774
easyway@newtrix.ca
www.newtrix.ca



instructions

easyway™ collar
newtrix.ca

newtrix.ca

PROVEN EFFECTIVE


Every dog is different, so the first time you use your easyway collar, it is important to adjust the fit for your dog's maximum comfort and safety.

Follow these simple steps to find the perfect fit for your new collar. After that, just slide the easyway on, attach it to your dog's regular collar and leash, and enjoy your walk.




Fitting the NewTriX **easyway™** collar


newtrix.ca



1. Hold the collar vertically with the fleece nosepiece in one hand.




2. Place the pointer finger of your other hand on the strap between the two metal rings. Pull the strap down as far as it will go toward the slidlock to form a double loop.



3. Bring your hands to meet at the top of the fleece nosepiece, forming one large loop, like a horse bridle or halter.




4. Guide your Dog's nose through the gathered loops with the chin ring under the chin. Place the fleece on the nose while you bring the double loops (push-pulley mechanism) over his ears.



5. The straps will form an "X" underneath your dog's chin.



6. When first fitting the easyway, snug the slidlock behind your dog's head to a position that's comfortable, but won't allow the nosepiece to slip off.




7. Connect the safety clasp to your dog's regular collar. (if no adjustment required, attach your leash to the leash ring located beside the NewTriX label and enjoy your walk.)

SATISFACTION GUARANTEED

NewTriX Inc., warrants the NewTriX easyway™ collar will be free from defects in materials, workmanship and design affecting normal use, for a period of one year from the original retail purchase date. All claims under this warranty must be submitted, in writing, to NewTriX Inc., with original proof of purchase. In the event that NewTriX Inc., in its sole discretion, finds a defect covered by this limited warranty, NewTriX Inc. will repair, replace or refund the defective product. NewTriX liability is limited to the value of the product. There are no other warranties, express or implied. NewTriX is not responsible for indirect, special, incidental or consequential damages of any kind resulting from any breach of warranty, negligence or negligent manufacture.



8. If the nosepiece rests too close to your dog's eyes, remove the easyway collar. Feed strap through the button slides to lengthen the cheek straps, making sure both sides are equal. The cheek straps should just pucker out a little and only become tense if you try to pull the nosepiece forward.



9. If your dog cannot yawn fully, remove the easyway collar and feed strap through the button slides to lengthen the chin straps.